



Installation Guide

Date: 11/1/2018

Garage Door Models: FFNF05

Unmatched Value - Superior Performance

- FOLLOW ALL LOCAL BUILDING CODES AND ALL FEMA/NFIP INSTALLATION REQUIREMENTS AND REGULATIONS
- REVIEW THESE INSTRUCTIONS BEFORE INSTALLATION ● INSPECT VENTS FOR DAMAGE AND TO MAKE SURE THE GRILL IS PROPERLY CENTERED BETWEEN THE RAISED TABS ON THE BOTTOM

1. CUT A 8"H x 16"W ROUGH OPENING IN THE GARAGE DOOR. *SAFETY REMINDER: PROTECT YOUR EYES AND HANDS DURING THE INSTALLATION PROCESS. TIP: GRINDERS WITH 4" WHEELS WORK WELL DURING THIS STEP.*
2. MARK THE LOCATION OF EACH HOLE AND DRILL 1/4" HOLES IN EACH OF THE FOUR CORNERS OF THE FLOOD VENT'S EXTERIOR TRIM FRAME.



3. INSERT FLOOD VENT INTO ROUGH OPENING TO MAKE SURE IT FITS. USE THE FLOOD VENT TO MARK THE LOCATION FOR THE HOLES IN THE GARAGE DOOR. REMOVE FLOOD VENT AND USE MARKS TO DRILL 1/4" HOLES IN GARAGE DOOR.

4. PLACE FLOOD VENT BACK IN GARAGE DOOR. APPLY FASTENERS TO EXTERIOR OF THE FLOOD VENT BY PUSHING THEM THROUGH THE FOUR PRE-DRILLED HOLES. *TIP: EXTERIOR GRADE SILICONE CAN BE APPLIED AROUND THE EXTERIOR FRAME (BEFORE APPLYING FASTENERS) IF ADDED INSULATION IS DESIRED.*



INTERIOR TRIM INSTALLATION GUIDE

APPLY INTERIOR TRIM FRAME BY PUSHING THE FRAME OVER THE EXPOSED ENDS OF THE FOUR FASTENERS. *NOTE: FOR INSULATED GARAGE DOORS, FOUR ADDITIONAL FASTENERS WILL BE PROVIDED FOR INSTALLING INTERIOR FRAME. TIP: EXTERIOR GRADE SILICONE CAN BE APPLIED AROUND THE INTERIOR FRAME IF ADDED INSULATION IS DESIRED.*

